



SkipDr Replacement Kit Quick Start Guide

1. **REMOVE** any disc from repair device before replacing FlexiWheel™.
2. **PULL** used FlexiWheel™ out of repair device (slip finger behind wheel to pop it off of hub prongs).
3. **INSERT** new FlexiWheel™ into device, align with hub prongs and press firmly to attach wheel.

Note: Logo on center hub of wheel should be facing out. It may be necessary to slightly rotate or jiggle wheel to position it onto hub prongs.